

# MOTORCYCLE GAUGE INSTALL

The illumiglo gauges install over the stock gauges. Remove any screws, if any, in the face prior to installing the new gauges.

1. Peel up the adhesive backing about half way. Cut off half with a pair of scissors. Try to make sure it's a half with no holes, so you can see the holes when lining it up.
2. Replace the cut off backing offset so some of the adhesive is exposed. This will let you still slide the gauge over the needle without it sticking as you slide it.
3. Insert the needle into the hole of the new gauge face.
4. Slide the needle all the way down to the base of the needle, then press down on the new face to have it go under the base. (don't worry the gauges are flexible and will bend slightly to fit)
5. Slide the new gauge toward the tail of the needle until it touches the needle shaft. This will allow the gauge clearance to fit over the tail of the needle.
6. Slide the gauge down over the tail and realign it to lay on top of the stock face.
7. Once aligned, press the exposed adhesive down to hold it in place. Then gently bend the face up so you can remove the adhesive backing. Just enough to remove the backing. Rub down the face from the center to the outer edge. Then do this with the other half of the backing.

Reinstall any screws removed through the new face and stock face.

Do this with any remaining faces, then reassemble the gauge cluster.

